

#### **Installation Instructions** & User Guide

Please leave these instructions with the end user

Product code: GWF BASNW C (D1)

### **Specifications**

**Dynamic Water Pressure** 







Maximum Static Pressure: 10.0bar

#### Inlet water temperature

Cold Water Supply **Hot Water Supply** 





Inlet Connections

#### Tools you'll need









Recommended Maximum





#### **Prior to Installation**

All products manufactured and supplied by Bristan are safe provided they are installed, used correctly and receive regular maintenance in accordance with this instruction.

This product needs to be installed in accordance with, and meet the requirements of the Water Supply (Water Fittings) Regulations 1999 and Scottish Bye-laws 2004.

For product specific installation requirements, please visit www.wras.co.uk

Isolation valves must be fitted to the inlet water supplies to ensure ease of future maintenance.

Before installing this product the water supply must be thoroughly flushed in order to remove any swarf, solder etc.


This product must not be modified in any way as this will invalidate the

Full access must be made available for future maintenance / servicing purposes.


If in doubt, contact a registered plumber or your Local Water Authority or the Secretary of the Institute of Plumbing, address as follows;-


The Institute of Plumbing, 64 Station Lane. Hornchurch, RM12 6NB, Tel: 01708 472791


#### **Pack Contents**



## Flexible Connecting pipes









#### Installation

Screw the flexi tails into the bottom of the mixer body. (Do not overtighten)






Place the plinth over the hole in the basin ensuring that the washer is fitted between the plinth and the basin




Feed the flexi tails through the hole in the basin.





Slide the 'C' shaped rubber washer and the 'C' shaped metal washer onto the fixing rods up to the underside of the basin. To secure the mixer in place tighten the fixing nuts onto the fixing rod until they fully tightened against the 'C' shaped metal washer.



Connect the flexi tails to the hot and cold water supplies. Turn on the mains water supply letting the water flow for a few minutes to flush through the system. Check all joints and connections for any




### Why not visit our YouTube channel

To see our latest how-to videos, simply scan the QR code with your smart phone or tablet.




Alternatively visit www.youtube.com/bristantv




# **Maintenance - Cartridge Cleaning**

Prior to doing any maintenance or servicing, isolate the water supply to the basin mixer.










Replace the handle,

tighten the grub

the cap

screw and push fit



Remove the cartridge and clean thoroughly under cold water to remove any build up of lime-scale or debris.

Turn the water

supply on.





Replace the cartridge into the body. Tighten the cartridge retaining nut using suitable spanner.



# **Spare Parts**

To replace any spare parts for your bath shower mixer why not scan the QR code and search for your product





Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces.

All surfaces will wear if not cleaned correctly, the only safe way to clean your mixer tap is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids will damage the surface of your fitting, even the non-scratch cleaners.

Note: Never use abrasive detergents or disinfectants or those containing alcohol, hydrochloric acid or phosphoric acid.

Troubleshooting	
Cause	Remedy
partially closed isolation valve.	Open isolation valve.
Instantaneous water heater cycles on and off as flow rate or pressure is too low.	Increase water flow rate or pressure through system.
Head of water is below the minimum distance required.	2 meters minimum required.
Hot or cold water being drawn off elsewhere causing pressure changes or instantaneous boiler temperature changes.	Do not use other water outlets when using the taps.
Air lock or partial blockage in the supply pipe work.	Flush through pipe work to ensure removal of debris and any air locks.
This is normal for a short time after using the taps.	This is caused by capillary action, the build up of water in the tap body.
If water continues to drip, possibly due to the ceramic disc valves	Remove valves and clean, refer to 'Maintenance' section before starting any maintenance.
	Cause  partially closed isolation valve.  Instantaneous water heater cycles on and off as flow rate or pressure is too low.  Head of water is below the minimum distance required.  Hot or cold water being drawn off elsewhere causing pressure changes or instantaneous boiler temperature changes.  Air lock or partial blockage in the supply pipe work.  This is normal for a short time after using the taps.  If water continues to drip,

#### Notes

Taps do not

turn on

Closed isolation valve.

Mains water supply turned off.

Please use this space for any notes you or your installer may have regarding the installation of this product.

Open isolation valve.

Turn on mains water supply.

At Bristan, we want to make things as easy as possible for our customers. That's why we offer solid guarantees on all our products, effective from the date of purchase, to give you peace of mind.

To start your free quarantee simply scan the QR code and register your product, alternatively visit www.bristan.com/register.

For any other queries, please call our Customer Service on 03300266273 where our expert team of advisors will be able to offer you any help and advice.

For full guarantee terms and conditions visit www.bristan.com/guarantees.



