

## Fitting instructions

1. Prepare circular hole in floor 100mm (4") minimum, 150mm (6") maximum, 75mm (3") deep.
2. Push the decorative cover (1) onto the lower portion of the upright tube (2), and screw the locknut (14) on to the thread as far as it will go.
3. Screw the mounting flange (3) onto the upright tube.
4. Push the water feed block (4) over the exposed pipe ends, taking care not to damage the O rings. We recommend the use of a smear of petroleum jelly over the O rings before fitting.
5. Rotate the mounting flange until the 2 inner holes align and secure with M6 cap screws. Tighten the locknut (14) on to the top face of the mounting flange
6. Screw the flexible pipes (6) into the ports in the water feed block.
7. Fasten the mounting flange to the floor using suitable screws (not supplied).
8. Push the decorative cover onto the floor.
9. Apply petroleum jelly to the seal (8) and fit in top of upright tube.
10. Screw the collar (9) into the top of the tube, hand tightened only.
11. Remove the O ring (10) from the spout.
12. Fit the hose (11) to the outlet, and the handset (12) to the hose ensuring sealing washers (13) are in place.
13. Connect the flexible pipes to supply and check thoroughly for leaks.