

## Installation & operating guide



### Box contents:

- Manual single lever body with handle fitted.
- 12mm x 1/2" BSP flexible inlet pipes x 2.
- 1/2" x 1/2" BSP outlet/spout connecting pipe.
- Mirror screws x 4
- Plastic wall plugs x 4
- Fast fix spout
- Hose and handset – (bath shower mixer option only)

### Assembly instructions:



Remove the brass spindle from the spout by loosening grub screw.



Push the threaded part through the plate from the front.



Fit the rubber washer and screw the backnut up to it from behind the plate.



Attach in the flexible inlet pipes. Do not over tighten. These are to be plumbed into hot & cold water supplies. Flush out the pipes prior to this to remove any debris.



Attach the outlet/spout connection pipe to the connector from the back of the body to the spout thread using the 1/2" BSP flexible pipe. A loop must be made so the pipe can be pushed upwards or downwards into the wall recess.



Using the mirror screws and wall plugs provided, fix the assembled plate into the wall, after the plumbing connections have been made. The joints should be checked for leaks. Note: A wall baton may be needed to attach the screws into to make a solid fix. A small bead of silicone sealant needs to be added to the back of the plate to make a water tight seal.



Attach the spout by pushing it over the brass spindle. Please make sure the grub screw is fully removed so the O rings do not become damaged. Line up the spout, and tighten grub screw. The mixer is now fully operational by using the handle.

**On the Bath shower mixer version, the hose may now be connected to the bottom of the spout, and to the handset. The handset will fit into the parking bracket when not in use.**

### **Aftercare**

To maintain the appearance of the flow controller periodically it should be cleaned with a soft damp cloth. The use of abrasive or solvent cleaners will damage the finish of the product and should not be used.

**Helpline number: 01282 446789**  
**www.ultra-group.co.uk**