



Troubleshooting

Symptom	Cause	Rem
No flow or low flow rate	Partially closed isolation valve.	Ope
	Instantaneous water heater cycles on and off as flow rate or pressure is too low.	Incre
	Head of water is below the minimum distance required.	2 m
	Hot or cold water being drawn off elsewhere causing pressure changes or instantaneous boiler temperature changes.	Do r
	Air lock or partial blockage in the supply pipe work.	Flus and
Water dripping from taps	This is normal for a short time after using the taps.	This wate
	If water continues to drip, possibly due to the ceramic disc valves	Rem sect
Taps do not turn on	Closed isolation valve.	Ope
	Mains water supply turned off.	Turn

Notes

Please use this space for any notes you or your installer may have regarding the installation of this product.

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces.

All surfaces will wear if not cleaned correctly, the only safe way to clean your mixer tap is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids will damage the surface of your fitting, even the non-scratch cleaners.

Note: Never use abrasive detergents or disinfectants or those containing alcohol, hydrochloric acid or phosphoric acid.

To replace any spare parts for your bath shower mixer why not scan the QR code and search for your product



At Bristan, we want to make things as easy as possible for our customers. That's why we offer solid guarantees on all our products, effective from the date of purchase, to give you peace of mind.

To start your free guarantee simply scan the QR code and register your product, alternatively visit www.bristan.com/register.

For any other queries, please call our Customer Service on 03300266273 where our expert team of advisors will be able to offer you any help and advice.

For full guarantee terms and conditions visit www.bristan.com/guarantees.

nedy

en isolation valve.

rease water flow rate or pressure through system.

neters minimum required.

not use other water outlets when using the taps.

sh through pipe work to ensure removal of debris l any air locks.

is is caused by capillary action, the build up of ter in the tap body.

move valves and clean, refer to 'Maintenance' tion before starting any maintenance.

en isolation valve.

n on mains water supply.



We Know & We Care